



**INSTRUCTIONS
FOR
YOUR**



WINCHESTER.




**MODEL
270
SLIDE ACTION
RIFLE**



HOW TO OPERATE

1. Open action to insure that rifle is unloaded, then close action.
2. Put on safety by pushing button from left to right until red band disappears.



3. Twist magazine tube plug to unlock and pull tube out until follower clears loading port.
4. Load magazine, then push tube in. Twist magazine tube plug to lock. Care should be taken while pushing tube in as it is under spring tension.



5. To load chamber, depress disconnecter and pull forearm back, then push fully forward.
6. To fire, take off safety by pushing button from right to left so that red band appears.

TO ADJUST SIGHTS


- 1.** If gun is shooting low, rotate rear sight elevator until a higher number appears opposite the arrow on the right side of the base. Rotate in the opposite direction if gun is shooting high.




- 2.** If gun is shooting to the left, the coin screw in the base should be turned in a counter clockwise direction. Turn in the opposite direction if gun is shooting to the right of point of aim.

HOW TO TAKE DOWN

- 1.** Open action to insure that rifle is unloaded, then close action.
- 2.** Put safety on.
- 3.** Twist magazine tube plug to unlock and pull out inside tube.
- 4.** Remove rear mounting pin by pushing out from either side. To remove trigger guard assembly, pivot back end down then pull back.




- 5.** Disengage locking plate from slide arm by pulling forearm to the rear, lift slide arm to clear bolt and push forearm forward. Bolt and locking plate are now free to lift out.




HOW TO ASSEMBLE



- 1.** ▲ **Locate locking plate in bolt recess.** Push forearm forward and lift slide arm. Insert locking plate and bolt under slide arm. Pull back forearm slowly until arm drops into bolt recess. ▼



- 2.** With forearm pulled back approximately $\frac{1}{2}$ inch, locate trigger guard front mounting pin into receiver hole and pivot into position. Insert rear mounting pin flush with receiver. ▼



- 3.** Insert magazine inside tube and lock.



WINCHESTER.

For nearly a century, WINCHESTER repeating firearms have established a world-wide reputation for reliability and accuracy, both in sporting arms as well as their military counterparts. These years of experience and manufacturing know-how, combined with the latest in engineering design and manufacturing methods, are your assurance that the new Winchester Model 270 is the finest rifle of its type on the market today.

COMPLETELY MODERN!

MODERN DESIGN. Perfectly balanced, graceful contours make the Model 270 extremely fast handling and a natural pointer.


MODERN METHODS. The latest in manufacturing skills assure accuracy, reliability and sure-fire functioning.

MODERN EQUIPMENT. The newest types of production machinery make it possible for you to get hand-crafted standards of quality at a popular price.

MODERN MATERIALS. Space age materials guarantee strength and durability.



WINCHESTER-WESTERN DIVISION
NEW HAVEN 4, CONNECTICUT



**CARE
OF
YOUR**
WINCHESTER[®]
**MODEL
270**

Protect your new rifle with good gun care products, give it regular attention, and it will give you year-after-year of shooting fun. Avoid excessive use of cleaning solvents on the tough composition action slide handle, magazine tube spacer and pistol grip cap.